



K99-XX23955-01 Snowmobile Pull Handle



 **TOOLS:**

- Vice Grip Pliers (1)
-

Step 1 — Removing handle



- Remove OEM pull handle knot being sure to not let pull rope retract back into spool.
- ⓘ Can be helpful to use vice grip pliers to pinch rope to avoid loss of rope into spool.

Step 2 — New handle



- Thread pull rope through new Zbroz pull handle and tie knot to secure rope to handle
- ⓘ Some handles have a guard that comes with to keep handle from rattling. Be sure to replace if provided.