



POLARIS GENERAL 4 1000 / RZR S 4 900 / RZR S 4 1000 (2016-2020) *4 SEATER MODELS



Kit Includes:

- (2) Front Main Springs
- (2) Front Tender Springs
- (2) Rear Main Springs
- (2) Rear Tender Springs
- (4) Spring Dividers
- (8) Spring Retainers

Installation Instructions:

1. Lift RZR and remove tires.
2. Loosen Pre-Load Rings to top of the shock body.
3. Remove lower shock bolt and slightly loosen top shock bolt.
4. Swing shock outward and remove Lower Spring Retainer, Lower Main Spring, Spring Divider, Upper Tender Spring and Upper Spring Retainer. **All of these to be replaced with this spring kit.*
5. Using all new Spring Kit, install Upper Spring Retainer, Upper Tender Spring, Spring Divider, Main Spring and Bottom Spring Retainer. **See Spring Stack Order*
6. Tighten Pre-Load Rings enough to hold new Spring Kit firmly in place.
7. Position shock and tighten upper and lower shock bolts.
8. Measure spring stack from Lower Spring Retainer to Upper Spring Retainer.
9. Tighten Pre-Load Rings an additional .25" from measurement and install tires.
10. Lower RZR to the ground, torque lug nuts, test drive RZR and adjust Pre-Load as preferred.

SPRING STACK ORDER

