



K82-0601 Turbo S A Arms



INTRODUCTION

PLEASE RETAIN THIS DOCUMENT FOR FUTURE REFERENCE

IF your ZBROZ® product has a damaged or missing part, please contact customer service directly and a new replacement part will be sent to you immediately.

For warranty issues, please return to the place of installation and contact ReadyLIFT.

Business hours are Monday through Friday 8AM-5PM MST.

PHONE: (435) 753-7774

EMAIL: customerservice@zbrozracing.com

WEBSITE: www.zbrozracing.com

LIMITED LIFETIME WARRANTY

Zbroz Racing will warranty to the original purchaser any failed Zbroz Racing suspension product in the event of failure due to construction or material failure of the product. You will be required to contact Zbroz Racing customer service with descriptions and photos that resulted in failure.

Zbroz Racing builds suspension products to meet and exceed your expectations in quality, performance and durability. All Zbroz Racing suspension products are rigorously tested during development and prototype parts are pushed to the limit by professional industry athletes, backcountry athletes and race teams. Zbroz Racing Limited Lifetime Warranty excludes the following wear parts as these parts are considered defective when worn: Ball Joints, Bushings, Bump Stops, Tie Rod Ends, Heim Joints, Shock Absorbers Product purchased directly from Zbroz Racing has a 90 day return policy on uninstalled products from the date of purchase (may be subject to restocking fee). Uninstalled product returns must be in the original Zbroz Racing packaging. Please call (435) 753-7774 to get an RGA# for any return. Customer is responsible for shipping costs back to Zbroz Racing. Returns without RGA# will be refused. Contact Zbroz Racing directly about any potentially defective parts prior to removal from vehicle.

Zbroz Racing is NOT responsible for any subsequent damages to any related vehicle parts due to misuse, abuse, improper installation, or lack of maintenance. Furthermore, Zbroz Racing reserves the right to change, modify or cancel this warranty without prior notice.

FOLLOW INSTRUCTIONS TO ENSURE PROPER INSTALLATION

READ INSTRUCTIONS THOROUGHLY AND COMPLETELY BEFORE BEGINNING INSTALLATION. INSTALLATION BY A CERTIFIED PROFESSIONAL MECHANIC IS HIGHLY RECOMMENDED. READYLIFT IS NOT RESPONSIBLE FOR ANY DAMAGE OR FAILURE RESULTING FROM IMPROPER INSTALLATION.



TOOLS:

- Ratchet (1)
- 15mm Socket (1)
- 15mm End Wrench (1)
- 18mm Socket (1)
- 18mm End Wrench (1)
- T40 Torx (1)
- Rivet gun (1)
- Drill and 3/16" Drill bit (1)
- 16mm End Wrench (1)



PARTS:

- Lower Right Hand A-Arm (1)
- Lower Left Hand A-Arm (1)
- Upper Right Hand A-Arm (1)
- Upper Left Hand A-Arm (1)
- EYELET REDUCER SS -10 X 12MM 1.768 (1)
- EYELET REDUCER SS -10 X 12MM .267 (1)
- EYELET REDUCER SS -10 X 12MM .533 (1)
- EYELET REDUCER SS -10 X 12MM .133 (1)

Step 1 — Safety Warning



- **MISUSE OF THIS PRODUCT COULD LEAD TO INJURY OR DEATH.** You should never operate your vehicle under the influence of alcohol or drugs. All raised vehicles have increased risk including blind spots; damage, injury and/or death can occur if these instructions are not followed.
- Suspension systems or components that enhance the on and off-road performance of your vehicle may cause it to handle differently than it did from the factory. Extreme care must be used to prevent loss of control or vehicle rollover during abrupt maneuvers.
- Always operate your vehicle at reduced speeds to ensure your ability to control your vehicle under all driving conditions. Failure to drive safely may result in serious injury or death to driver and passengers. You should never operate your vehicle under the influence of alcohol or drugs.
- Driver and passengers must **ALWAYS** wear your seat belts, avoid quick sharp turns and other sudden maneuvers. ZBROZ does not recommend the combined use of suspension lifts, body lifts, or other lifting devices.

- Constant maintenance is required to keep your vehicle safe. Thoroughly inspect your vehicle before and after every off-road use.
- It is the responsibility of the retailer and/or the installer to review all state and local laws, with the end user of this product, related to bumper height laws and the lifting of their vehicle before the purchase and installation of any ReadyLIFT products.
- It is the responsibility of the driver to check their surrounding area for obstructions, people, and animals before moving the vehicle.
- All raised vehicles have increased blind spots; damage, injury and/or death can occur if these instructions are not followed.


Step 2 — Installation Warning



- All steps and procedures described in these instructions were performed while the vehicle was properly supported on a two post vehicle lift with safety jacks.
- Use caution during all disassembly and assembly steps to insure suspension components are not over extended causing damage to any vehicle components and parts included in this kit.



- Included instructions are guidelines only for recommended procedures and are not meant to be definitive. Installer is responsible to insure a safe and controllable vehicle after performing modifications.
- ZBROZ recommends the use of an OE Service Manual for model/year of vehicle when disassembly and assembly of factory and related components.
- Unless otherwise specified, tighten all bolts and fasteners to standard torque specifications listed within the OE Service Manual.
- Suspension components that use rubber or urethane bushings should be tightened with the vehicle at normal ride height. This will prevent premature wear or failure of the bushing and maintain ride comfort.
- Larger tire and wheel combinations may increase leverage on suspension, steering, and related components.
- Due to payload options and initial ride height variances, the amount of lift is a base figure. Final ride height dimensions may vary in accordance to original vehicle ride height. Always measure the vehicle ride height prior to beginning installation.

Step 3



- Begin by making sure you are parked on a flat surface. Using a floor jack, raise the front end of your Turbo S and remove the front wheels and tires.
- **(IMAGE 1)** With an 18mm end wrench and socket, disconnect the sway bar.
- **(IMAGE 2)** Using a 3/16 drill bit, remove the four rivets holding the brake line to the upper a-arm.
- Use an 18mm end wrench and socket to remove the lower shock mount bolt.
- **(i) NOTE:** It is not necessary to remove the shock completely. Use a strap or rope to hold it up out of the way as shown in **(IMAGE 3)**

Step 4




- **(IMAGE 1)** Remove the two 16mm bolts holding the brake caliper, This provides clearance to remove the upper and lower ball joints.
- **(IMAGE 2)** Using a 15mm end wrench and socket, remove the upper ball joint bolt. gently lift on the upper a-arm and the ball joint should come out.
- Remove the lower ball joint bolt and lift up on the hub assembly and the lower ball joint should fall out.

Step 5 — Removing Stock A-Arms




- **(IMAGE 1)** Using a T30 Torx remove the 2 screws holding the front cover in place. This will allow easier access to the upper A Arm Bolts.
- Remove the two 18mm lower a-arm bolts holding the arm to the frame.
 - ⓘ **NOTE:** The front bolt is shorter than the rear bolt. They will be reinstalled in the same location.
- Once those bolts are removed the a-arm should be free. Remove the OEM end caps and sleeve/pin. (there is only 1 sleeve/pin and its located in the longer pivot tube.) These will be used in reassembly.
- Next, use your 18mm to remove the upper control arm as well and set aside. you will not reuse the OEM sleeve/pin or the end caps from the upper arm.
 - ⓘ **NOTE:** On the upper a-arm the rear bolt is shorter than the front bolt and will reinstalled in the same location.

Step 6 — Assembling ZBROZ Lower A-Arms




- **(IMAGE 1 & 2)** Place the OEM Sleeve/Pin and end caps into the new ZBROZ a-arm pivot tubes the same way they were in the stock a-arm pivot tubes. Notice the caps will go with the taper towards the outside like stock.
- ⓘ **NOTE:** The Sleeve/pin shown in **(IMAGE 1)** will be installed into the rear pivot tube on the lower a-arm. The hat shaped caps, shown in **(IMAGE 2)**, will be installed into the front pivot tubes.
- ⓘ **NOTE:** The new ZBROZ a-arms will come with ball joints and bushing pre installed.

Step 7 — Installing ZBROZ Lower A-Arms



- **(IMAGE 1)** Begin reinstalling the new ZBROZ a-arms by placing the pivot tubes into the frame side and securing them with the correct bolts. The longer bolt goes in the rear pivot tube and the shorter bolt goes in the front pivot tube.
- **(IMAGE 2)** Next reinstall ball joint into steering knuckle and secure using the proper bolt.
- **(i) (IMAGE 3)** Using a dead blow hammer will be helpful in getting the ball joint back into place.
- Repeat the above steps on the opposite side.
- Tighten all hardware back to factory torque specifications.

Step 8 — ZBROZ Upper A-Arms



- Assemble the new ZBROZ upper a-arm by placing the eyelet spacers in the proper Locations. see **(IMAGE 1)** for proper placement.
- Once you have the spacers in the correct position, go ahead and install the arm by putting the long bolt through the front mounting position and the short bolt through the rear mounting position. torque the nut and bolt to the factory torque specifications.
- Once you have your bolts through and have tightened to the factory torque specifications, replace the upper ball joint into the hub assemble by raising the hub assembly enough for the ball joint to fall into place. torque the nut and bolt to the factory torque specifications.
- Now that the upper a-arm is in place, attach the break line to the upper arm using three of the rivets provided.
- After you have the break line in place, go ahead and replace the lower shock mount and torque to factory specifications.
- **(IMAGE 2)** With the upper and lower arms in place, replace the brake caliper using the two 16mm bolts and tighten to factory torque specifications.
- Repeat all the above steps on the other side, replace wheels and tires and lower the vehicle.

By installing this product, you acknowledge that the suspension of this vehicle has been modified. As a result, this vehicle may handle differently than that of factory-equipped vehicles. As with any vehicle, extreme care must be used to prevent loss of control or roll-over during sharp turns or abrupt maneuvers. Always wear seat belts, and drive safely, recognizing that reduced speeds and specialized driving techniques may be required. Failure to drive this vehicle safely may result in serious injury or death. Do not drive this vehicle unless you are familiar with its unique handling characteristics and are confident of your ability to maintain control under all driving conditions. Some modifications (and combinations of modifications) are not recommended and may not be permitted in your state. Consult your owner's manual, the instructions accompanying this product, and state laws before undertaking these modifications. You are responsible for the legality and safety of the vehicle you modify using these components.